



FN 15[®] Tactical Carbine Gen II CA Owner's Manual Addendum



We are pleased that you have chosen an FN 15[®] Tactical Carbine Generation II CA. The FN 15[®] Tactical Carbine Gen II CA shares the same reliability, durability, quality and many of the operating features as other FN 15[®] rifles and carbines. However, it has additional special features such as a match-grade barrel, a free-float forearm, a HERA featureless buttstock, ambidextrous selector and a Surefire muzzle break. This addendum will cover the operation of those specific features where they differ from the standard FN 15[®]. The common operations and features of the FN 15[®] Auto loading Rifle are included in the Owner's Manual supplied with your FN 15[®] Tactical Carbine.

WARNING

Before inspecting or making any adjustments on the FN 15[®] Tactical Carbine Gen II CA fully read and understands completely the Owner's Manual as well as this Addendum. Place the "safety" in the on safe position, remove the magazine, open the action and ensure the chamber is empty as explained in Section 15.1 of your Owner's Manual. Always keep the muzzle pointed in a safe direction. Failure to follow these warnings may result in serious injury or death.

1. Contents of the Storage Case

- FN 15[®] Tactical Carbine Gen II CA, with Owner's Manual and this addendum
- MEGA Arms accessory pack (wrench kit)
- HERA CQR Manual
- Safety lock and two keys
- One 10-round Magpul[®] PMAG[™] magazine

2. Special Features and Components of the FN 15[®] Tactical Carbine Gen II CA

The FN 15[®] Tactical Carbine Gen II CA is equipped with several special components carefully selected to provide an additional level of performance.

In most cases, these features require no additional instruction beyond those for the standard components.

1. A hammer forged, chrome-plated 16" barrel chambered in 5.56x45mm NATO for increased accuracy, long life and ease of cleaning. It features a NAROH Steel Low Profile Gas Block, pinned.
2. A mid-length gas system and "H" buffer to soften recoil and provide smooth operation.
3. A Surefire muzzle brake that greatly reduces both recoil impulse and muzzle rise for quicker follow-up shots.
4. FN Wedge Lock Rail Assembly, 13.625" in length
5. HERA CQR rifle stock with Sling-Swivel sockets and 45mm insert
6. MagPul[®] GenM3 PMAG[™] 10 rounds for longer life and increased durability

WARNING

Before manipulating or making accessories adjustments, place the "safety" in the on safe position, remove the magazine, open the action and ensure the chamber is empty as explained in Section 15.1 of your Owner's Manual. Always keep the muzzle pointed in a safe direction. Failure to follow these warnings may result in serious injury or death.

3. Free Float Handguard



The FN Wedge Lock Rail Assembly 13.625" lightweight free-float forearm/rail on the FN 15® Tactical Carbine Gen II CA is in place of the standard round handguards. The rail assembly extends over a low profile gas block. It allows for mounting of additional grips, sights, laser devices and other accessories onto a rigid, free-float forearm. Additional M-LOK™ slots fill the rest of the rail.

WARNING

Before installing any sights, lasers or other devices on the rifle, place the "safety" in the on safe position, remove the magazine, open the action and ensure the chamber is empty as explained in Section 15.1 of your Owner's Manual. Always keep the muzzle pointed in a safe direction. Failure to follow these warnings may result in serious injury or death.

3.1 M-LOK™ Rail Installation

M-LOK™ accessory rail are not supplied, but can be attached to the forearm assembly in multiple locations on the left, right and bottom sides. To install an M-LOK™ rail to the forearm, first ensure the rifle is completely unloaded, completely clear and the safety lever is placed in the "on safe" position as described in Section 15.1 of your Owner's Manual. M-LOK™ rails will not fit under the gas block. M-LOK™ rails and accessories are available directly from Magpul®. (www.magpul.com)

WARNING

Do not mount any sight, laser, or other device, which interferes with normal operation of the rifle or extends beyond or in front of the muzzle. Ensure any sight or device attached on this rail is firmly mounted.

CAUTION

Use care when disassembling the upper and lower receivers as described in Section 18.1 of your Owner's Manual with the Wedge Lock rail. Damage may occur to the rail and the lower receiver if done improperly. A pinch hazard may also be present!

3.2 Disassembly: FN does not recommend removing or disassembling the FN Wedge-, lock rail system for normal maintenance as some retaining compound is used. It should remain attached to the upper receiver for normal maintenance.



When dis-assembling the rifle as explained in Section 18.1, use extra care when separating the upper and lower receivers. Because of the mounting device on the rail, there is less clearance between the rail and the lower receiver. If the upper receiver is pivoted on the front take-down pin as shown in Figure 20 of the Owner's Manual, the rail may come in contact with the lower receiver causing damage to the rail, the lower receiver and potentially pinching your hand. Please use caution.

WARNING

Before installing, making any adjustments to or removing sights, lasers or other devices on the rifle, place the "safety" in the on safe position, remove the magazine, open the action and ensure the chamber is empty as explained in Section 15.1 of your Owner's Manual. Always keep the muzzle pointed in a safe direction. Failure to follow these warnings may result in serious injury or death.

THIS PAGE LEFT BLANK INTENTIONALLY